


RIVAL[®]_____

Automatic Can Opener/ Sharpener



Model CN732

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Please read all instructions.
2. To protect against risk of electrical shock, do not put cord, plug or power unit in water or other liquid.
3. Close supervision is necessary when any appliance is used by or near children.
4. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
5. Avoid contacting moving parts.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or is dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or electrical or mechanical adjustments.
7. The use of attachments not recommended or sold by the appliance manufacturer may cause fire, electric shock or injury.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not open pressurized (aerosol-type) cans or cans of flammable liquids, such as lighter fluids.
11. To disconnect, remove plug from wall outlet.

SAVE THESE INSTRUCTIONS


- Power unit never needs lubrication.
- This appliance is for **HOUSEHOLD USE ONLY**.
- No user-serviceable parts inside. Do not attempt to service this product.

POLARIZED PLUG

This appliance has a polarized plug (one blade is wider than the other). As a safety feature this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

TO OPEN CANS


1. Plug cord into 120 volt, AC outlet.
2. Raise piercing lever enough to wedge can between cutting blade and feed gear as shown.
3. Press lever down all the way to pierce lid and start cutting action. "Power Pierce" feature: When you press lever, motor will start rotating can for easier piercing.
4. Let go of lever and can opener will continue cutting and will stop automatically when can has been opened. (It is normal for motor to occasionally continue cutting action for a few seconds after lid has been severed.)
5. To remove can, grasp it firmly and raise lever. Slide lid from magnet.



TO SHARPEN KNIVES

Do not attempt to sharpen hollow ground blades or those with serrated edges.


1. Be sure knife is clean and free of grease.
2. Place heel of knife into the "V". Lightly draw blade toward you, applying a slight downward pressure. Repeat this procedure four to five times to put on a "factory sharp" edge.



TO CLEAN

Never submerge can opener in water.

1. Unplug cord. Lift piercing lever to its most upright position. Hold appliance and ease cutting assembly out of case. Wash in hot, soapy water. Rinse and dry. Do not wash in automatic dishwasher.
2. To replace, hold piercing lever in upright position as shown. Insert shaft into large round section of keyhole. Push in piercing lever all the way. Rotate piercing lever clockwise until piercing lever is horizontal. If lever is properly engaged, it cannot be removed from can opener when in horizontal position.



HINT: Cutting mechanism may collect food or paper from can labels, and should be washed frequently.

LIMITED ONE-YEAR WARRANTY

The Rival Company warrants this product to be free from defects in materials or workmanship for one (1) year from date of original purchase. If you have a claim under this warranty please follow these procedures:

- 1) **Within the first 45 days** from date of original purchase, defective product should be returned to original place of purchase for replacement (with proof-of-purchase).
- 2) **Within the first 12 months** from date of purchase Rival will repair or replace (at no charge) the defective product if it is delivered freight prepaid during that period to an authorized service station. To obtain warranty service contact our CUSTOMER SERVICE DEPARTMENT between 8:00 a.m. and 4:30 p.m. Central Standard Time, Monday through Friday (for prompt service have model number and sales receipt ready)

In U.S. call: 1-800-557-4825

In Canada call: 1-800-363-3479

Or, you may write to Rival's Service Division, 217 East 16th St., Sedalia, MO 65301.

Proof of purchase is required when requesting warranty service - **SAVE YOUR SALES RECEIPT**. This warranty is extended only to the original purchaser and does not apply to commercial use, unreasonable use, or to damage to the product (not resulting from defect or malfunction) while in the possession of the consumer. The Rival Company disclaims all responsibility for consequential, incidental, or commercial losses caused by the use of this product. Some states do not allow this exclusion or limitation of incidental or consequential losses, so the foregoing disclaimer may not apply to you. This warranty gives you specific legal rights, and you may also have other legal rights which vary from state to state. This warranty is valid in the United States and Canada only.